

GENERAL INSTALLATION INSTRUCTIONS FOR BLACK STAINLESS STEEL SHOWER DRAINS

APZ1BLACK



APZ101BLACK



During the installation, extra care must be taken to avoid any mechanical or chemical damage to the paint (e.g. handling tools, concreting, paving, grouting).

Fill the gap between the pavement and the edge of the shower drain with chemically non-aggressive silicone with a neutral pH.

We strictly do not recommend the use of classic joint compound, the use of which risks mechanical or chemical damage to the paint surface.

The manufacturer is not responsible for any mechanical or chemical damage to the surface that occurred during installation or during subsequent use by the customer.

More information on warranty, warranty certificate or general recommendations for cleaning and maintenance can be found on Alcadrain website:

www.alcadrain.com/en/customer-services/warranty-and-warranty-certificate